Dell Series 6 & 11
Start-up & Troubleshooting

Message Shown	Action Steps
On LCD Printer: Black & Color Ink low	Press (√) button (on printer) to continue. An automatic alignment page will start printing. Wait until alignment page completes printing. Ready to print.
Reserve Tank: Your black & color ink cartridges are below the minimum ink level...(cont.)	Check (√) the square box "☑ Don't display this dialog again." Click [Continue Printing].
Dell AIO low ink warning	Check (√) the square box "☑ I have already ordered my ink. Please don't remind me again." Click [Close].
Align the cartridge Print the alignment page	Click [Print] to print the alignment page. Follow instructions and wait until alignment page is finished. Click [Close].
Resend the print job	Click [Close] and resend the print job.

Note: Please do not skip any "Action Steps". Doing so will cause the messages to continue to pop up.